



### Rubber-Cement „VUM“ (open-pored)



	„VUM2“	„VUM70“
<b>Granule size</b>	0,5 – 2,5 mm	1 – 4 mm
<b>Thickness</b>	10, 15 or 20 mm	10, 15 or 20 mm
<b>Weight/kit</b>	30,5 kg	30,5 kg
<b>1 kit for...</b>	3 m <sup>2</sup> in 10 mm, 2 m <sup>2</sup> in 15 mm, 1,5 m <sup>2</sup> in 20 mm	
<b>Delivery package</b>	1 kit: 25 kg pre-treated rubber granules, 5 kg binder, 0,5 kg primer	
<b>Material</b>	Pre-treated rubber granules / Polyurethane-binder The cured product is open-pored.	
<b>Working-time</b>	Install mixtures within 15-30 minutes.	
<b>Storage</b>	PU-binder app. 6 months, rubber granules app. 36 months	
<b>Standard Colour</b>	black-grey-mixed-coloured	
<b>Cleaning-interval</b>	Use a garden hose or a high pressure washer in regular intervals (3 month recommended). Put the pressure washer to medium strength only.	
<b>Sample kit (for trials and repairs)</b>	Available in kits of 5kg granules, 1 kg binder and 0,25 kg primer, for app. 0,5m <sup>2</sup> in 10mm thickness	

**Requirements:** Install only at temperatures of more than 10 degrees C. Apply in well ventilated areas. No form of moisture (rain, fog, snow are to be present while assembling and at least 24h after assembling.

Bound subground, e.g. wood, metal, cement, use double amount of primer on absorbent surfaces. Test the material on problematic surfaces.

**Places of use and recommended thicknesses:**

horse-transporters / stall aisles	10 mm
wash racks / chutes	15 mm
guiding circles	20 mm

**Installation/Assembling:** 1. Pre-treatment of floor with primer 1103. Let dry for 4 – 6 h. 2. Mix 5 kg of granules and 1 kg of binder for min. 3 minutes. 3. Supply evenly on floor by using a lath suitable to reach the required thickness. 4. Compress by using a trowel or suitable tool. 5. Continue from point 2 until area is finished 6. Let dry for min. 24 hours until finished.

A detailed installation-sheet is provided with every delivery.

**Tolerances and note about material:** Colour differences between kits may occur, due to the recycling character of the material. We recommend to mix different kits, especially for larger areas.

Siemensring 25  
53925 Kall  
Germany

Tel. +49 (0)2441 5037  
Fax +49 (0)2441 5039

info@err-team.de

more ...  
Information,  
examples of use,  
installation guidelines &  
Tips at:

[www.err-team.de](http://www.err-team.de)