


DATASHEET

Solid Rubber Mat SMART



<i>Article number</i>	9SMA10
<i>Thickness</i>	10 mm
<i>Dimensions</i>	app. 100 x 100 cm, plus 2,5cm puzzle connectors
<i>Installation</i>	loose, screwing possible
<i>Unit</i>	pce. (1,0 m ²)
<i>Weight/ Unit (kg)</i>	11 kg
<i>Surface design</i>	raindrop pattern
<i>Bottom design</i>	flat
<i>Standard colours</i>	black
<i>Material</i>	new rubber
<i>Tolerances</i>	length and width: +/- 1%, thickness: +/-2mm
<i>Fire Class (EN 13501-1:2010)</i>	E_{fl}
<i>Installation</i>	Let mats adjust to room temperature for 24 hours. Place puzzle connectors over each other and step on the connectors – or use a rubber hammer. Use some kind of alignment to receive straight area outlines. Leave app. 1-2cm from each connecting wall since rubber tiles are likely to expand. Cut by using a fret saw or a carpenter knife.
<i>Cleaning</i>	Avoid great amounts of dirt on the rubber mat by using appropriate solutions in all entrance areas. The rubber mats can be vacuum / broom cleaned. If using water and a mild detergent make sure to only use a moist but not totally wet cloth. Too much water could be soaked under the mats. For the same reason, spilled liquids need to be removed in a timely manner.